

Customer Facing Screens

- [2 line Customer Display](#)
- [2nd Monitor Customer Facing Screen](#)

2 line Customer Display

The 2 line customer display we usually supply connects to the back of the Posiflex terminal. It connects via a small USB cable it is supplied with and there is a panel you can remove on the top left on the back of the Posiflex which has a USB socket it can connect to.



Once it is connected put the files from the Posiflex customer display folder in the intouch folder on the s: drive in the Winci folder on the server.

In the program go into options and the setup tab and then click more and the customer Display options should be on the right.

First Choose which port the Display is connected too. The drop down has a list of COM ports but the Posiflex USB we usually use is at the bottom of the list.

Receipt	Kitchen	Charges	Reports	Restaurant	Order Screen	Security	Set-Up
YesPay CC Authorisation Allowed Yes Print Name & Address None <input type="checkbox"/> Doesn't Print Shop Copy <input type="checkbox"/> Doesn't Load Yespay				Caller ID Type 3 Port Number 7 Caller ID File None			
VAT Standard Rate 17.50 Rate 2 0.00 Rate 3 0.00 <input type="checkbox"/> Refunds are Standard Rate <input type="checkbox"/> Pizzas Vat Rate 0 <input type="checkbox"/> All Standard Rate <input type="checkbox"/> "Hot" Button Adds Standard Rate VAT <input type="checkbox"/> Restaurant Service Charge Is VAT Exempt				Customer Display <div> <div>1</div> <div>Port No. None</div> <div>Type 2</div> </div> <div> <div>2</div> <div>Port No. None</div> <div>Type None</div> </div>			
Euro Exchange rate <input type="checkbox"/> Display on Receipt Currency Symbol £				MSR Reader - Driver Port No. None			
Map Co-ordinates Bottom Right Shop Cell X 0 Y 0 Scale (meters) 0 Print Distance on Receipt Yes				Show Courses Days/Time <div></div>			
Target Screen <input type="checkbox"/> Visible Time 0 Make Time 0 Out Door Time 0 Delivery Time 0 <input type="checkbox"/> Upload							
<div>Abort</div>				<div>Save & Exit</div>		<div>More</div>	

Then choose the type of Customer Display from the drop down. The list comprises different types of Customer Display but the one we usually use is the USB HID choice on the list.

Receipt	Kitchen	Charges	Reports	Restaurant	Order Screen	Security	Set-Up
---------	---------	---------	---------	------------	--------------	----------	---------------

YesPay CC Authorisation

Allowed Yes

Print Name & Address None

☐ Doesn't Print Shop Copy

☐ Doesn't Load Yespay

VAT

Standard Rate	17.50
Rate 2	0.00
Rate 3	0.00

☐ Refunds are Standard Rate

☐ Pizzas Vat Rate 0

☐ All Standard Rate

☐ "Hot" Button Adds Standard Rate VAT

☐ Restaurant Service Charge Is VAT Exempt

Euro

Exchange rate

☐ Display on Receipt

Currency Symbol £

Map Co-ordinates

Bottom Right

Shop Cell X Y

Scale (meters)

Print Distance on Receipt Yes

Target Screen

☐ Visible Time

Make Time

Out Door Time

Delivery Time

☐ Upload

Caller ID

Type 3 Port Number 7

Caller ID File None

Customer Display

1

Port No. 2

Type None

2

Port No. VFD 450

Type Pro Touch

MSR Reader - Driver

Port No. N

Show Courses Days/Time

Abort
Save & Exit
More

The 2 line Customer Display will display the shop name and time normally. When you are in an order it will display each item you choose and its price. At the end of the order it will say "Total Amount" and display the total amount of the order.


2nd Monitor Customer Facing Screen

The 2nd screen we usually supply connects to the back of the Posiflex terminal. It connects via a small USB cable it is supplied with and there is a panel you can remove on the top left on the back of the Posiflex which has a USB socket it can connect to.



The machine with the display needs a folder in the winci folder called images that has at least 2 .JPG files in it.

It needs a space and then /EF on the command line after the wcimani.exe on the server



or in the intouch.bat file if it is a terminal

```

*INTOUCH - Notepad
File Edit Format View Help
@ECHO OFF
: TOP
IF EXIST \\server\c\winci\wcimain.exe (xcopy \\server\c\winci\data\*. * c:\winci\data\ /D /Y) ELSE GOTO TOP
IF EXIST \\server\c\winci\wcimain.exe (xcopy \\server\c\winci\audit\*. * c:\winci\audit\ /D /Y) ELSE GOTO TOP
IF EXIST \\server\c\winci\wcimain.exe (\\server\c\winci\wcimain.exe /EF) ELSE GOTO TOP
|
Ln 6, Col 1    100%    Windows (CRLF)    UTF-8

```

Below is a link to the Posiflex site to the drivers for the screen we normally supply.

<https://www.posiflex.com/en-global/product/index/POS-Monitor/Attachment/LM-6810U#download>

When the driver is installed there should be 2 screens showing in the display settings and this screen needs to be to the left of the main screen.

There is a power button on the back of the small screen if it doesn't seem to work.

It should just display whatever is in the images folder as a slideshow and if you go into an order it should display the receipt being built up on the right like it does on the order screen.