

# Printers

- [How to install the Star TSP143II \(USB\)](#)
- [How to install the Integer U80II \(USB\)](#)
- [How to share your printer and add it to another computer](#)
- [Adding a logo to a Star TSP100 printer](#)
- [Installing the Bixolon Boxedge printer.](#)
- [How to install the Integer U80II \(Ethernet\)](#)

# How to install the Star TSP143II (USB)

**Unbox your Star TSP143II (USB)**

[image-1623247445044.png](#)

Image not found or type unknown

**Plug the power cable into the back of the printer and plug socket**

[image-1623247612338.png](#)

Image not found or type unknown

**Then plug the USB cable into the back of the printer and USB port into your computer**

**image-1623247772668.png**

Image not found or type unknown

**Once the green light is on go to 'Control Panel'**

**image-1623248097139.png**

Image not found or type unknown

**Click on 'Devices and Printers'**

[image-1623247996906.png](#)

Image not found or type unknown

**Double click on 'Star TSP100 Cutter (TSP143)'**

[image-1623248206155.png](#)

Image not found or type unknown

**Click the 'Printer' tab**

[image-1623248260603.png](#)

Image not found or type unknown

**Then click on 'Properties'**

[image-1623248317892.png](#)

Image not found or type unknown

**Click in the box that says 'Star TSP100 Cutter (TSP143)'**

[image-1623248696484.png](#)

Image not found or type unknown

**Rename it to 'Receipt'**

[image-1623248737834.png](#)

Image not found or type unknown

**Then click 'OK'**

[image-1623248632461.png](#)

Image not found or type unknown

**To check that the printer works go to 'Properties'**

[image-1623248317892.png](#)

Image not found or type unknown

**In the 'General' tab**

[image-1623249220065.png](#)

Image not found or type unknown

**At the bottom click on 'Print Test Page'**

[image-1623249299090.png](#)

Image not found or type unknown

**This will then do test page**

[image-1623249378961.png](#)

Image not found or type unknown

**Then on the Server in inTouch go to 'Management'**

[image-1623413441740.png](#)

Image not found or type unknown

**Click on 'Occasional Menu'**

[image-1623413468507.png](#)

Image not found or type unknown

**Then 'Options'**

[image-1623413497979.png](#)

Image not found or type unknown

**In the 'Receipt' tab**

[image-1623413538994.png](#)

Image not found or type unknown

**You will then see 'Printer Type'**

[image-1623413607830.png](#)

Image not found or type unknown

**Click on the drop down**

[image-1623413644452.png](#)

Image not found or type unknown

**Select 'Star TSP143'**

[image-1623413897506.png](#)

Image not found or type unknown

**Then 'Save & Exit'**

**image-1623413728988.png**

Image not found or type unknown

**And 'Exit'**

**image-1623413749749.png**

Image not found or type unknown

**And 'Main Menu'**

**image-1623413774861.png**

Image not found or type unknown

**Then just do a test print**

**image-1623413819780.png**

Image not found or type unknown

**If you need to share the printer please see document 'How to share your printer and add it to another computer'**

# How to install the Integer U80II (USB)

**\*\*\*Please call us to get the U80II printer driver\*\*\***

**Unbox your Integer U80II (USB)**

[image-1623341637318.png](#)

Image not found or type unknown

**Plug the power cable into the back of the printer and plug socket**

[image-1623247612338.png](#)

Image not found or type unknown

**Then plug the USB cable into the back of the printer and USB port into your computer**

[image-1623247772668.png](#)

Image not found or type unknown

**Turn the printer on**

[image-1623410852743.png](#)

Image not found or type unknown

**Once the green light is on go to 'File Explorer'**

[image-1623411102632.png](#)

Image not found or type unknown

**Click on 'This PC'**

[image-1623411184445.png](#)

Image not found or type unknown

**Then go to 'C: Drive'**

[image-1623411221731.png](#)

Image not found or type unknown

**Click on the 'Integer' folder**

[image-1623411257587.png](#)

Image not found or type unknown

**Open the folder 'Setup\_U80 V1.12' folder**

[image-1623411297821.png](#)

Image not found or type unknown

**Double click on the 'Setup.exe'**

[image-1623411386115.png](#)

Image not found or type unknown

**Click on the 'Receipt' drop down and select 'U80II'**

[image-1623411481106.png](#)

Image not found or type unknown

**Click on 'Next'**

[image-1623411562972.png](#)

Image not found or type unknown

**And 'Next' again**

[image-1623411578925.png](#)

Image not found or type unknown

**Then click on 'Install'**

[image-1623411627164.png](#)

Image not found or type unknown

**Once the driver has installed click 'OK'**

[image-1623411760761.png](#)

Image not found or type unknown

**You will then need to go to the 'Control Panel'**

[image-1623248097139.png](#)

Image not found or type unknown

**Click on 'Devices and Printers'**

[image-1623247996906.png](#)

Image not found or type unknown

**Double click on 'U80II(U)'**

[image-1623412608189.png](#)

Image not found or type unknown

**Click the 'Printer' tab**

[image-1623248260603.png](#)

Image not found or type unknown

**Then click on 'Properties'**

[image-1623248317892.png](#)

Image not found or type unknown

**Click in the box that says 'U80II(U)'**

[image-1623248696484.png](#)

Image not found or type unknown

**Rename it to 'Receipt'**

[image-1623248737834.png](#)

Image not found or type unknown

**Then click 'OK'**

[image-1623248632461.png](#)

Image not found or type unknown

**To check that the printer works go to 'Properties'**

[image-1623248317892.png](#)

Image not found or type unknown

**In the 'General' tab**

[image-1623249220065.png](#)

Image not found or type unknown

**At the bottom click on 'Print Test Page'**

[image-1623249299090.png](#)

Image not found or type unknown

**This will then do test page**

[image-1623249378961.png](#)

Image not found or type unknown

**Then on the Server in inTouch go to 'Management'**

[image-1623413441740.png](#)

Image not found or type unknown

**Click on 'Occasional Menu'**

[image-1623413468507.png](#)

Image not found or type unknown

**Then 'Options'**

[image-1623413497979.png](#)

Image not found or type unknown

**In the 'Receipt' tab**

[image-1623413538994.png](#)

Image not found or type unknown

**You will then see 'Printer Type'**

[image-1623413607830.png](#)

Image not found or type unknown

**Click on the drop down**

[image-1623413644452.png](#)

Image not found or type unknown

**Select 'Epson Thermal'**

[image-1623413692972.png](#)

Image not found or type unknown

**Then 'Save & Exit'**

[image-1623413728988.png](#)

Image not found or type unknown

**And 'Exit'**

[image-1623413749749.png](#)

Image not found or type unknown

**And 'Main Menu'**

[image-1623413774861.png](#)

Image not found or type unknown

**Then just do a test print**

[image-1623413819780.png](#)

Image not found or type unknown

**If you need to share the printer please see document 'How to share your printer and add it to another computer'**

# How to share your printer and add it to another computer

**In control panel, go to Device and Printers, and printer properties**

image-1624366476422.png

Image not found or type unknown

**Go to 'Sharing' tab and tick 'Share this printer'**

image-1624366613555.png

Image not found or type unknown

**Then go to the 'Security' tab allow all permissions for 'Everyone'.**

image-1624366718131.png

Image not found or type unknown

**If 'Everyone' isn't there, click 'Add' and then type "Everyone" and click 'OK'.**

image-1624366909435.png

Image not found or type unknown

**Go back to 'Control Panel' and click 'Network and Sharing Centre'**

**image-1624367138547.png**

Image not found or type unknown

**Click 'Change advanced sharing settings'**

**image-1624367086889.png**

Image not found or type unknown

**In 'Private' settings:**

**-Select 'Turn on network discovery' and tick 'Turn on automatic setup of network connected devices.'**

**-Select 'Turn on file and printer sharing'**

**image-1624367306501.png**

Image not found or type unknown

**In 'Guest or Public' settings:**

**-Select 'Turn on network discovery'.**

**-Select 'Turn on file and printer sharing'**

**image-1624367395116.png**

Image not found or type unknown

**In 'All Networks' settings:**

**-Select 'Enable file sharing for devices that use 40- or 56- bit encryption'.**

**-Select 'Turn off password protected sharing'**

**image-1624367479132.png**

Image not found or type unknown

**Open 'File Explorer' and right click your C: Drive and click 'Properties'.**

**image-1624367561249.png**

Image not found or type unknown

**Go to the 'Sharing' tab and click on 'Advanced Sharing'**

**image-1624367636403.png**

Image not found or type unknown

**Tick 'Share this folder' and click on 'Permissions'.**

**image-1624367777202.png**

Image not found or type unknown

**Add 'Everyone' and allow all permissions. 'Apply' and click 'OK'**

**image-1624367817648.png**

Image not found or type unknown

**Navigate to the 'Security' tab and allow "Everyone" full control by ticking allow for all options.**

**image-1624367907857.png**

Image not found or type unknown

**Navigate to: (C:/Windows/ System32/ spool) and Right click "PRINTERS" and go to 'Properties'**

**image-1624368036344.png**

Image not found or type unknown

**Once again, go to the 'Sharing' tab, click 'Advanced Sharing', tick 'Share this folder', click 'Permissions' and add "Everyone".**

**image-1624368148094.png**

Image not found or type unknown

**Then once again, navigate to the 'Security' tab and allow "Everyone" full permissions by ticking allow for all options.**

**image-1624368215083.png**

Image not found or type unknown

**To add a shared printer, go to 'Device and Printers' in the Control Panel and click "Add a printer"**

**image-1624368377911.png**

Image not found or type unknown

**Click 'The printer that I want isn't listed:'**

**image-1624368438783.png**

Image not found or type unknown

**Add a local printer**

**image-1624368465052.png**

Image not found or type unknown

**Keep clicking "Next" until it asks for the "printer name". Put:**

**"\\server\reciept"**

**image-1624368593850.png**

Image not found or type unknown

# Adding a logo to a Star TSP100 printer

If you go into Control Panel by holding the windows key and pressing R to bring up the run box and typing control panel.

[star logo 4.jpg](#)

Image not found or type unknown

Then choose Devices and Printers.

[star logo 5.jpg](#)

Image not found or type unknown

Choose the printer you want the logo on (usually receipt).

[star logo 6.jpg](#)

Image not found or type unknown

Choose printer and then on the drop down choose properties.

[star logo 7.jpg](#)

Image not found or type unknown

Choose TSP100 Config.

[star logo 8.jpg](#)

Image not found or type unknown

Click Launch Configuration Application.

[star logo 9.jpg](#)

Image not found or type unknown

The choose Star Line Mode and click OK.

[star logo 2.jpg](#)

Image not found or type unknown

The Star utility will now be displayed.

[star logo 3.jpg](#)

Image not found or type unknown

First choose Image list.

Select the image you want to be printed.

Then choose Logos & Cropping and select the image to be at the top and centred.

# Installing the Bixolon Boxedge printer.

The Boxedge Label printer we usually supply is the Bixolon XD5 40d with a cutter or previously we supplied the Bixolon SLP-DX420CG with a cutter. The cutter is important when the printer is purchased as it can't be fitted afterwards on the SLP-DX420CG but can on the newer XD5 40d . The labels are Zebra labels, Part no. 800263-105 and the size is (mm) 76.2 x 25.4 (3 inch by 1 inch).



The printer has USB, LAN and serial connections. If it is closer to a machine the USB connection can be used, If it is further away it can be setup as LAN or serial. The serial connection on the back of the printer is a 9 pin and the pin out for the serial to RJ45 adapters are in the notes folder on the fileserver. If the printer is connected to the serial port the speed of the port may need to be changed. To do this on the printer properties go to the ports tab. Click on the "Configure Port..." button and change the Bits Per Second setting from the default 9600 to 115200.

The driver is on the Bixolon site.

[https://bixolon.com/download\\_view.php?idx=34](https://bixolon.com/download_view.php?idx=34)

SLP-DX420CG

[https://bixolon.com/download\\_view.php?idx=132](https://bixolon.com/download_view.php?idx=132)

XD5 40d

Further down the page in the Application section and Utility there is the net configuration tool (which can find the printer on the network if that is how it is connected) and the Unified Label Utility (which can reset the printer to factory default and recalibrate the labels amongst other things).

Once the printer is installed if you rename it Boxedge you are then ready to set it up in the program.

If you go into Management.

27/03/21 10:37

**Delivery**

**TakeAway**

**Restaurant (1)**

**Assign To Driver**

**Collect**

**Payment By Driver**

**Bookings**

**Shut Down**

**Management**

**No Sale**

Then Occasional Menu.

**27/05/21 10:39**

**Today's Takings**

**Today's Orders**

**Expenses**

**Purge Printer**

**Message**

**Support**

**Occasional Menu**

**Main Menu**

Then Options.



Then click on the Kitchen printer tab and more the Boxedge options are on the right,

Receipt Printer	Kitchen Printer	Charges	Reports	Restaurant	Order Screen	Security	Set-Up
-----------------	-----------------	---------	---------	------------	--------------	----------	--------

Top Gap

Bottom Gap

Cutter 

Partial

Double Height

Group Items

Course Gap

Action on Amended Order

Lines Gap Before Items

Item Print

None

Merge Stock Items

None

Print Amendments to Order

0

Wide Description - No Value

☒ Buzzer

☒ Print Cancelled Orders

☐ Print in Capitals

☒ Don't Print Shop Name

☐ Reprint Order Also Reprints Kitchen Printout

☐ Prints Delivery Method

☐ Prints Bottom same as Receipt

☐ Prints Assistant Name

☐ Print Kitchen Same as Receipt

☐ All Printers Print as Kitchen Printer 1

☐ Prints Total

☐ Asks to Print

☒ Prints Order Time

☐ Prints Copy on Receipt Printer

☐ Reprints on Collection

☐ Only Prints from Make Line Screen

Printers

	Name	Type
1	Pizza	Star SP200
2	Counter	Star SP200
3		No Printer
4	Kebabs & Burgers	Star SP200
5		No Printer

Prints Normal Receipt as Well on Printers

Print Name

Gap

Copies

All Stock Items Printer

Doesn't Print if Takeaway on Courses

No

Line Between Items (not Cho

1

None

☐

Pizzas

Pizzas Printer

Pizzas Printer 2

1

-

Red

None

Abort

Save & Exit

More

Receipt Printer	<b>Kitchen Printer</b>	Charges	Reports	Restaurant	Order Screen	Security	Set-Up
<div> <div> <b>Make Line</b>  Type By Order-Item Selectable  Orders for Later Don't Display until Default Tim  Unfinalised Orders Can Edit &amp; Accept  Makeline on Main Screen All  Printer Only 2  Display Minutes to Delivery  Print Box Edge Label When First item Made  Choices Display  Finalises Order Take Away  <input type="checkbox"/> Displays Assign to Kitchen + Default T/A Time  <input type="checkbox"/> Prints Receipt when Order Completed  <input checked="" type="checkbox"/> Puts Toppings on As few lines As possible  <input type="checkbox"/> No. of Completed Orders on Assign Button  <input type="checkbox"/> Displays Non-Stock Qualifiers with Main Item  <input type="checkbox"/> ML2 Doesn't Display if Items on ML1  <input type="checkbox"/> Prints Receipt to Kitchen when bumped off M/L  <input type="checkbox"/> Order-Item Selectable Groups + Items Together  <input type="checkbox"/> ML2 only Displays Restaurant Orders  <input type="checkbox"/> Doesn't Display Quantity Column  <input type="checkbox"/> Displays Page at a Time  <input type="checkbox"/> Only Allow 1 Screen at a Time  <input checked="" type="checkbox"/> Beeps When New Items Occur  <input type="checkbox"/> Reloads Every 15 Seconds  <input type="checkbox"/> Smaller Buttons  <input type="checkbox"/> Show Delivery Address  <input type="checkbox"/> Assign Doesn't Assume Made  Doesn't Display - Split ML1 0 </div> <div> <b>Box Edge Label Printer</b>  Type Bixelon SLP-DX420  Summary Label Always  Each Label Prints Order Number  Action on Take Away Print  Action on Amended Order No Action  Multiple -  <input type="checkbox"/> Doesn't Print Label For Pizzas  <input type="checkbox"/> Doesn't Print Name or Phone Number  <input type="checkbox"/> Always Asks to Print  <input checked="" type="checkbox"/> Stock &amp; Quals on Same Label  <input type="checkbox"/> Puts Paid or To Pay On Summary  <b>Alternate Printer</b>  Type None  <input type="checkbox"/> Prints Delivery Method  <input type="checkbox"/> Prints Values  <input type="checkbox"/> Prints Address &amp; Telephone No. (for Deliveries)  <input type="checkbox"/> No Line Gap </div> </div>							
<div> <div>Abort</div> <div>Save &amp; Exit</div> <div>More</div> </div>							

In the options the first drop down is for the type of printer. There is a list of printer we have used with the system in the past. The Bixelon printer is near the bottom. At the bottom is an option for Bixelon No Cutter as sometimes if a printer has been purchased with no cutter this option needs to be used. If the normal Bixelon option is used the code to cut is sent and as the printer has no cutter it shows a red light and goes into an error state. The labels do have perforations so can be separated but it is better if the printer has a cutter.

The next option is if a summary label is to produced for each order. For each order it produces a label for each item that is set to print its own label. It can print a summary label for the order with the order number and total price.

It can Also print a sundry label that puts together all the items that you have chosen to go on a sundry label.

**TAKEAWAY**

**T/A No.56  
11:05**

Summary  
Label

**£29.47**

**1 Mozz Ch Sticks  
Chilli Sauce  
1 Chilli Pepper & Chee  
Garlic Sauce  
1 Chilli Stuffed Jalap  
BBQ Sauce**

**T/A No.56  
11:05**

Sundry  
Label

**3 of 3**

**10" Thin Meat Special**

**T/A No.56  
11:05**

Item  
Label

**2 of 3**

**8" Thin Margarita**

**T/A No.56  
11:05**

**1 of 3**

To specify if an item is printed on a label at all, prints on its own label or prints on the sundry label

if you click on an item in the menu section and go into the details tab of an item and there is Boxedge Label drop down. From this you can choose if an item has a label printed and if so what type.

[illegible]

# How to install the Integer U80II (Ethernet)

**\*\*\*Please call us to get the U80II printer driver\*\*\***

**Unbox your Integer U80II**

[image-1623341637318.png](#)

Image not found or type unknown

**Plug the power cable into the back of the printer and plug socket**

[image-1623247612338.png](#)

Image not found or type unknown

**Then plug the Ethernet cable into the back of the printer and a port into your router**



**Turn the printer on**

[\*\*image-1623410852743.png\*\*](#)

Image not found or type unknown

**Once the green light is on go to 'File Explorer'**

[\*\*image-1623411102632.png\*\*](#)

Image not found or type unknown

**Click on 'This PC'**

[\*\*image-1623411184445.png\*\*](#)

Image not found or type unknown

**Then go to 'C: Drive'**

[\*\*image-1623411221731.png\*\*](#)

Image not found or type unknown

**Click on the 'Integer' folder**

[image-1623411257587.png](#)

Image not found or type unknown

**Open the folder 'Setup\_U80 V1.12' folder**

[image-1623411297821.png](#)

Image not found or type unknown

**Double click on the 'Setup.exe'**

[image-1623411386115.png](#)

Image not found or type unknown

**Click on the 'Receipt' drop down and select 'U80II'**

[image-1623411481106.png](#)

Image not found or type unknown

**Click on 'Next'**

[image-1623411562972.png](#)


Image not found or type unknown

**Click on 'Next'**

[image-1623411562972.png](#)

Image not found or type unknown

**On the next screen choose "Net" from the drop down and enter the printers IP address in the box and then click install at the bottom.**



The IP address of the printer is given out by you router so can be different on every network. To find out what it is on the printer power it off, hold the feed button and power it back on. You should now receive a test print from the printer and at the bottom it will give you the IP address of the printer. Press and release feed again to print a bit more of the test print and the printer will now be ready to work.

Once the driver has installed click 'OK'

[image-1623411760761.png](#)

Image not found or type unknown

You will then need to go to the 'Control Panel'

[image-1623248097139.png](#)

Image not found or type unknown

**Click on 'Devices and Printers'**

[image-1623247996906.png](#)

Image not found or type unknown

**Double click on 'U80II(E)'**



U80II(E)

**Click the 'Printer' tab**

**image-1623248260603.png**


Image not found or type unknown

**Then click on 'Properties'**

**image-1623248317892.png**

Image not found or type unknown

**Click in the box that says 'U80II(E)'**



**Rename it to 'Receipt'**

[image-1623248737834.png](#)

Image not found or type unknown

**Then click 'OK'**

[image-1623248632461.png](#)

Image not found or type unknown

**To check that the printer works go to 'Properties'**

[\*\*image-1623248317892.png\*\*](#)

Image not found or type unknown

**In the 'General' tab**

[\*\*image-1623249220065.png\*\*](#)

Image not found or type unknown

**At the bottom click on 'Print Test Page'**

[\*\*image-1623249299090.png\*\*](#)

Image not found or type unknown

**This will then do test page**

[\*\*image-1623249378961.png\*\*](#)

Image not found or type unknown

**Then on the Server in inTouch go to 'Management'**

[\*\*image-1623413441740.png\*\*](#)

Image not found or type unknown

**Click on 'Occasional Menu'**

[\*\*image-1623413468507.png\*\*](#)

Image not found or type unknown

**Then 'Options'**

[\*\*image-1623413497979.png\*\*](#)

Image not found or type unknown

**In the 'Receipt' tab**

[image-1623413538994.png](#)

Image not found or type unknown

**You will then see 'Printer Type'**

[image-1623413607830.png](#)

Image not found or type unknown

**Click on the drop down**

[image-1623413644452.png](#)

Image not found or type unknown

**Select 'Epson Thermal'**

[image-1623413692972.png](#)

Image not found or type unknown

**Then 'Save & Exit'**

[image-1623413728988.png](#)

Image not found or type unknown

**And 'Exit'**

[image-1623413749749.png](#)

Image not found or type unknown

**And 'Main Menu'**

[image-1623413774861.png](#)

Image not found or type unknown

**Then just do a test print**

image-1623413819780.png

Image not found or type unknown