

How to install the Integer U80II (USB)

*****Please call us to get the U80II printer driver*****

Unbox your Integer U80II (USB)

image.1623341637318.png

Plug the power cable into the back of the printer and plug socket

image.1623247612338.png

Then plug the USB cable into the back of the printer and USB port into your computer

image.1623247772668.png

Turn the printer on

image.1623410852743.png

Once the green light is on go to 'File Explorer'

image.1623411102633.png

Click on 'This PC'

image.1623411184445.png

Then go to 'C: Drive'

image.1623411221731.png

Click on the 'Integer' folder

image.1623411257587.png

Open the folder 'Setup_U80 V1.12' folder

image.1623411297821.png

Double click on the 'Setup.exe'

image-1623411386115.png

Image not found or type unknown

Click on the 'Receipt' drop down and select 'U80II'

image-1623411481106.png

Image not found or type unknown

Click on 'Next'

image-1623411562972.png

Image not found or type unknown

And 'Next' again

image-1623411578925.png

Image not found or type unknown

Then click on 'Install'

image-1623411627164.png

Image not found or type unknown

Once the driver has installed click 'OK'

image-1623411760761.png

Image not found or type unknown

You will then need to go to the 'Control Panel'

image-1623248097139.png

Image not found or type unknown

Click on 'Devices and Printers'

image-1623247996906.png

Image not found or type unknown

Double click on 'U80II(U)'

image-1623412608189.png

Image not found or type unknown

Click the 'Printer' tab

image-1623248260603.png

Image not found or type unknown

Then click on 'Properties'

image-1623248317892.png

Image not found or type unknown

Click in the box that says 'U80II(U)'

image-1623248696484.png

Image not found or type unknown

Rename it to 'Receipt'

image-1623248737834.png

Image not found or type unknown

Then click 'OK'

image-1623248632461.png

Image not found or type unknown

To check that the printer works go to 'Properties'

image-1623248317892.png

Image not found or type unknown

In the 'General' tab

image-1623249220065.png

Image not found or type unknown

At the bottom click on 'Print Test Page'

image-1623249299090.png

Image not found or type unknown

This will then do test page

image-1623249378961.png

Image not found or type unknown

Then on the Server in inTouch go to 'Management'

image-1623413441740.png

Image not found or type unknown

Click on 'Occasional Menu'

image-1623413468507.png

Image not found or type unknown

Then 'Options'

image-1623413497979.png

Image not found or type unknown

In the 'Receipt' tab

image-1623413538994.png

Image not found or type unknown

You will then see 'Printer Type'

image-1623413607830.png

Image not found or type unknown

Click on the drop down

image-1623413644452.png

Image not found or type unknown

Select 'Epson Thermal'

image-1623413692972.png

Image not found or type unknown

Then 'Save & Exit'

image-1623413728988.png

Image not found or type unknown

And 'Exit'

image-1623413749749.png

Image not found or type unknown

And 'Main Menu'

image-1623413774861.png

Image not found or type unknown

Then just do a test print

image-1623413819780.png

Image not found or type unknown

If you need to share the printer please see document 'How to share your printer and add it to another computer'

Revision #9

Created Thu, Jun 10, 2021 1:42 PM by Alec

Updated Fri, Jun 11, 2021 12:17 PM by Alec