

How to install the Integer U80II (USB)

*****Please call us to get the U80II printer driver*****

Unbox your Integer U80II (USB)

[image-1623341637318.png](#)

Plug the power cable into the back of the printer and plug socket

[image-1623247612338.png](#)

Then plug the USB cable into the back of the printer and USB port into your computer

[image-1623247772668.png](#)

Turn the printer on

[image-1623410852743.png](#)

Once the green light is on go to 'File Explorer'

[image-1623411102633.png](#)

Click on 'This PC'

[image-1623411184445.png](#)

Then go to 'C: Drive'

[image-1623411221731.png](#)

Click on the 'Integer' folder

[image-1623411257587.png](#)

Open the folder 'Setup_U80 V1.12' folder

[image-1623411297821.png](#)

Double click on the 'Setup.exe'

[image-1623411386115.png](#)

Image not found or type unknown

Click on the 'Receipt' drop down and select 'U80II'

[image-1623411481106.png](#)

Image not found or type unknown

Click on 'Next'

[image-1623411562972.png](#)

Image not found or type unknown

And 'Next' again

[image-1623411578925.png](#)

Image not found or type unknown

Then click on 'Install'

[image-1623411627164.png](#)

Image not found or type unknown

Once the driver has installed click 'OK'

[image-1623411760761.png](#)

Image not found or type unknown

You will then need to go to the 'Control Panel'

[image-1623248097139.png](#)

Image not found or type unknown

Click on 'Devices and Printers'

[image-1623247996906.png](#)

Image not found or type unknown

Double click on 'U80II(U)'

[image-1623412608189.png](#)

Image not found or type unknown

Click the 'Printer' tab

image-1623248260603.png

Image not found or type unknown

Then click on 'Properties'

image-1623248317892.png

Image not found or type unknown

Click in the box that says 'U80II(U)'

image-1623248696484.png

Image not found or type unknown

Rename it to 'Receipt'

image-1623248737834.png

Image not found or type unknown

Then click 'OK'

image-1623248632461.png

Image not found or type unknown

To check that the printer works go to 'Properties'

[image-1623248317892.png](#)

Image not found or type unknown

In the 'General' tab

[image-1623249220065.png](#)

Image not found or type unknown

At the bottom click on 'Print Test Page'

[image-1623249299090.png](#)

Image not found or type unknown

This will then do test page

[image-1623249378961.png](#)

Image not found or type unknown

Then on the Server in inTouch go to 'Management'

[image-1623413441740.png](#)

Image not found or type unknown

Click on 'Occasional Menu'

[image-1623413468507.png](#)

Image not found or type unknown

Then 'Options'

[image-1623413497979.png](#)

Image not found or type unknown

In the 'Receipt' tab

[image-1623413538994.png](#)

Image not found or type unknown

You will then see 'Printer Type'

[image-1623413607830.png](#)

Image not found or type unknown

Click on the drop down

[image-1623413644452.png](#)

Image not found or type unknown

Select 'Epson Thermal'

[image-1623413692972.png](#)

Image not found or type unknown

Then 'Save & Exit'

[image-1623413728988.png](#)

Image not found or type unknown

And 'Exit'

[image-1623413749749.png](#)

Image not found or type unknown

And 'Main Menu'

[image-1623413774861.png](#)

Image not found or type unknown

Then just do a test print

[image-1623413819780.png](#)

Image not found or type unknown

If you need to share the printer please see document 'How to share your printer and add it to another computer'

Revision #9

Created Thu, Jun 10, 2021 1:42 PM by [Alec](#)

Updated Fri, Jun 11, 2021 12:17 PM by [Alec](#)