How to install the Star TSP143II (USB)

Unbox your Star TSP143II (USB)

image_1623247445044.png

Image not found or type unknown

Plug the power cable into the back of the printer and plug socket

image_1623247612338.png

Image not found or type unknown

Then plug the USB cable into the back of the printer and USB port into your computer

image_1623247772668.png

Image not found or type unknown

Once the green light is on go to 'Control Panel'

image_1623248097139.png

Image not found or type unknown

Click on 'Devices and Printers'

image_1623247996906.png

Image not found or type unknown

Double click on 'Star TSP100 Cutter (TSP143)'

image_1623248206155.png

Image not found or type unknown

Click the 'Printer' tab

image_1623248260603.png

Image not found or type unknown

Then click on 'Properties'

image_1623248317892.png

Image not found or type unknown

Click in the box that says 'Star TSP100 Cutter (TSP143)'

image_1623248696484.png

Image not found or type unknown

Rename it to 'Receipt'

image_1623248737834.png

Image not found or type unknown

Then click 'OK'

image-1623248632461.png

Image not found or type unknown

To check that the printer works go to 'Properties'

image-1623248317892.png

Image not found or type unknown

In the 'General' tab

image-1623249220065.png

Image not found or type unknown

At the bottom click on 'Print Test Page'

image-1623249299090.png

Image not found or type unknown

This will then do test page

image-1623249378961.png

Image not found or type unknown

Then on the Server in inTouch go to 'Management'

image-1623413441740.png

Image not found or type unknown

Click on 'Occasional Menu'

image-1623413468507.png

Image not found or type unknown

Then 'Options'

image-1623413497979.png

Image not found or type unknown

In the 'Receipt' tab

image-1623413538994.png

Image not found or type unknown

You will then see 'Printer Type'

image-1623413607830.png

Image not found or type unknown

Click on the drop down

image-1623413644452.png

Image not found or type unknown

Select 'Star TSP143'

image-1623413897506.png

Image not found or type unknown

Then 'Save & Exit'

image-1623413728988.png

Image not found or type unknown

And 'Exit'

image-1623413749749.png

Image not found or type unknown

And 'Main Menu'

image-1623413774861.png

Image not found or type unknown

Then just do a test print

image-1623413819780.png

Image not found or type unknown

If you need to share the printer please see document 'How to share your printer and add it to another computer'

Revision #7

Created Wed, Jun 9, 2021 1:58 PM by Alec

Updated Fri, Jun 11, 2021 12:19 PM by Alec